



Technical Bulletin

G-Series Multiple Load Handler No Lube Decal

This sheet provides information on placement of decals for G-Series Multiple Load Handler arm bars. The front surface of the lower arm bars should not be lubricated or painted. Place decals on the outer side of inner arm bar sides, as shown. Clean surfaces before placing decals.

EN CAUTION: Do not lubricate or paint the lower arm bar front surface that the inner fork brake pads contact.

DE VORSICHT: Die vordere Fläche der unteren Armstange, die Kontakt mit den Bremsbelägen der Innengabel hat, darf weder abgeschmiert noch lackiert werden!


FR ATTENTION: Ne pas graisser ou peindre la surface avant de la traverse de bras inférieure venant au contact des plaquettes de frein de fourches intérieures.

ES ATENCIÓN: No lubrique ni pinte la superficie delantera del brazo inferior que hacen contacto con las zapatas de freno de la horquilla interior.

IT ATTENZIONE: Non lubrificare o verniciare la superficie anteriore dell'asta di guida del braccio inferiore, che viene a contatto con i pattini dei freni delle forche interne.

NL VOORZICHTIG: Breng geen smeermiddel of lak aan op het vooroppervlak van de onderste vorkstang waarmee de remblokken van de binnenvork contact maken.

Part No. 6086351



NOTE: This information should not be interpreted as the basis for warranty claims unless so designated.

cascade[®]
corporation

For Technical Support . . .

Call: 1-800-CASCADE (227-2233)

OR

Write: Cascade Corporation, PO Box 20187, Portland, OR 97294-0187

To Order Parts . . .

Call: 1-888-CASCADE (227-2233)

OR

Write: Cascade Corporation, 2501 Sheridan Ave., Springfield, OH 45505